

CLEANING NOTICE

Always remove Insight products from your weapon and remove the batteries before cleaning.

Insight recommends cleaning your accessories periodically to ensure proper working condition.

EXTERIOR OF UNIT: Use clean or mild, soapy water. Standard gun cleaning solvents (i.e., Hoppes) may be used to clean stubborn areas. Rinse with clean water to eliminate residue. Dry with a soft cloth.

NOTE: Avoid submerging lights to prevent liquids from pooling in the electrical contact area.

LENS: Clean with alcohol, clean water, or general purpose window cleaner.

ELECTRICAL CONTACTS: For cleaning of all electrical contacts (on rear cover, inside the unit, and on the bulb) use a cotton swab dipped in alcohol. To remove heavy build-up on the contacts, carefully rub with a standard pencil eraser (be sure to thoroughly remove eraser residue).

WARNING: Do not use highly basic, acidic, or flammable cleaning compounds. Do not use ultrasonic cleaning methods.

Designed, Developed, and Produced By



**INSIGHT
TECHNOLOGY
INCORPORATED**

3 Technology Drive, Londonderry NH 03053
Tel: 877-744-4802 Fax: 603-647-7234
www.insightlights.com

HELPFUL TIPS

- Keep silicone O-rings lubricated with a non-silicone, high temp stable grease to ensure the cleanliness of the inside of the bezel.
- Before shooting, to avoid a build-up of muzzle blast on the flashlight bezel lens, rub a small amount of oil or lubricating solvent on the exterior glass ONLY. This will make post-shooting clean-up easier.
- Do not overtighten any adjusters or set screws.
- Be sure to fasten bezel tight enough so it doesn't come loose during firing.
- For optimal performance of Insight Technology products, keep all contacts clean and dry.

If you have any questions please feel free to contact our
Customer Service Representative at
(877) 744-4802 ext. 1909 or
service@insightlights.com.